


Molded air fittings



RL100




MM ELBOW



Code	F	F1
RL10001	1/8	1/8
RL10002	1/8	1/4
RL10003	1/4	1/4
RL10004	3/8	3/8
RL10005	1/2	1/2
RL10006	3/4	3/4
RL10007	1"	1"

RL300




FF ELBOW



Code	F	
RL30001	1/8	
RL30002	1/4	
RL30003	3/8	
RL30004	1/2	
RL30005	3/4	
RL30006	1"	

RL200




MF ELBOW



Code	F	F1
RL20001	1/8	1/8
RL20002	1/8	1/4
RL20003	1/4	1/4
RL20004	3/8	3/8
RL20005	1/2	1/2
RL20006	3/4	3/4
RL20007	1"	1"

RT100




MMM TEE



Code	F	
RT10001	1/8	
RT10002	1/4	
RT10003	3/8	
RT10004	1/2	
RT10005	3/4	
RT10006	1"	

RT200



MFM TEE




Code	F	F1
RT20001	1/8	1/8
RT20002	1/4	1/4
RT20003	3/8	3/8
RT20004	1/2	1/2
RT20005	3/4	3/4
RT20006	1"	1"

RT400




FFF TEE



Code	F	
RT40001	1/8	
RT40002	1/4	
RT40003	3/8	
RT40004	1/2	
RT40005	3/4	
RT40006	1"	

RT300



MFF TEE




Code	F	F1
RT30001	1/8	1/8
RT30002	1/4	1/4
RT30003	3/8	3/8
RT30004	1/2	1/2
RT30005	3/4	3/4
RT30006	1"	1"

RT500




FMF TEE



Code	F	F1
RT50001	1/8	1/8
RT50002	1/4	1/4
RT50003	3/8	3/8
RT50004	1/2	1/2
RT50005	3/4	3/4
RT50006	1"	1"

RT600



MMF TEE




Code	F	F1
RT60001	1/8	1/8
RT60002	1/4	1/4
RT60003	3/8	3/8
RT60004	1/2	1/2
RT60005	3/4	3/4
RT60006	1"	1"

RC200




FFF CROSS



Code	F	
RC20001	1/8	
RC20002	1/4	
RC20003	3/8	
RC20004	1/2	

RC100



MFF CROSS




Code	F	F1
RC10001	1/8	1/8
RC10002	1/4	1/4
RC10003	3/8	3/8
RC10004	1/2	1/2


RV100



FMF Y



Code	F	F1
RV10001	1/8	1/8
RV10002	1/4	1/4
RV10003	3/8	3/8
RV10004	1/2	1/2




RV200

FEMALE Y



Code	F	
RV20001	1/8	
RV20002	1/4	
RV20003	3/8	
RV20004	1/2	



PRM200

ELBOW MALE HOSE ADAPTOR



Code	F	D	L	L1
PRM20001	1/8	6	22,5	14
PRM20002	1/8	6	23,5	14
PRM20003	1/8	6	38	21,5
PRM20004	1/8	7	22,5	14
PRM20005	1/8	7	32,5	14
PRM20006	1/8	7	38	21,5
PRM20007	1/4	6	23	14
PRM20008	1/4	6	32,5	14
PRM20009	1/4	7	23	14
PRM20010	1/4	7	32,5	14