




Valves • Cocks





VU100


FF NO RETURN VALVE O-RING VITON




Code	F	F1
VU001	1/8	1/8
VU002	1/4	1/4
VU003	3/8	3/8
VU010	1/2	1/2

VP100

VALVE OF START



Code	F	Setting range
VP001	1/4	BAR 1
VP002	1/4	BAR 1.5
VP003	1/4	BAR 2.2
VP004	3/8	BAR 1.5
VP005	3/8	BAR 3
VP006	3/8	BAR 1
VP007	1/4	BAR 3
VP008	3/8	BAR 2



VU200


MF NO RETURN VALVE O-RING VITON




Code	F	F1
VU005	1/8	1/8
VU006	1/4	1/4
VU007	8x1	1/8

RS100

DRAIN COCK



Code	F	Anti-unscrewing
RS001	1/4	
RS002	3/8	
RS003	1/8	
RS004	1/2	
RS005		1/8
RS006		1/4
RS007		3/8
RS008		1/2



RS200

DRAIN COCK WITH LEVER




Code	F	Anti-unscrewing
RSC001	1/8	
RSC002	1/4	
RSC003	3/8	
RSC008	1/2	
RSC004		1/8
RSC005		1/4
RSC006		3/8
RSC007		1/2




RSF100

FF BALL MINI-VALVE



Code	F	
RSF10001	1/8	
RSF10002	1/4	
RSF10003	3/8	
RSF10004	1/2	
RSF10005	3/4	



RCS100

SLIDING TAP




Code	F	
RCS10001	1/8	
RCS10002	1/4	
RCS10003	3/8	
RCS10004	1/2	




RSF200

MF BALL MINI-VALVE



Code	F	F1
RSF20001	1/8	1/8
RSF20002	1/4	1/4
RSF20003	3/8	3/8
RSF20004	1/2	1/2
RSF20005	3/4	3/4




RSF300

MM BALL MINI-VALVE




Code	F	
RSF30001	1/4	
RSF30002	3/8	
RSF30003	1/2	




RM200

MF BALL MICRO-VALVE




Code	F	F1
RM20001	1/8	1/8
RM20002	1/4	1/4




RM300

MM BALL MICRO-VALVE




Code	F	
RM30001	1/8	
RM30002	1/4	



RM100

FF BALL MICRO-VALVE




Code	F	
RM10001	1/8	
RM10002	1/4	



TLV

**VISUAL LEVEL INDICATOR WITH
GLASS OBSERVATORY (BRASS)**



Code	F	
TLV001	1/2	
TLV002	3/4	
TLV003	1"	
TLV004	1"1/4	
TLV005	1"1/2	
TLV006	2"	